



**Hit reset button before beginning

Digital Timer Cheat Sheet

To Program the Clock

1. Hold down clock button.
2. While holding down clock button set time by using hour and minute buttons.

To Program Date

1. Continue to hold down clock button and set day.
2. Let go of clock button (your day and time should be set now).
3. Hit program button once (on time).

To Program Your ON/OFF Settings (if you're using a photocell)

1. Press Program Button.
 - a. Select Program 1
 - b. Set your "ON", Program 1 time for 4:00pm. This only activates photo cell to start looking for darkness, won't turn lights on unless it is dark. This helps with Daylight Savings and prevents you from having to constantly adjust timer.
 - c. Hit Program Button again. Should say "OFF", Program 1. Set time to desired time. Make sure no other programs (by pressing Program Button again, (cycle through 8 programs) have times or you may overlap your settings causing inconsistent ON/OFF of your system.
2. Press Clock button to Finish.
4. Press the manual button until the screen says "Auto" & "On" with a small arrow appearing "Auto" label at bottom at screen
 - a. This will put your system in the current settings to operate properly.
 - b. By putting your system in the "Auto/On" setting, your system will come on until your photo cell notices it's still light outside and will then turn your system off and be ready for use.

****** Make sure to note am and pm on left side of screen.**